

DIGITUS Duvar kabinleri SOHO PRO - 483 mm (19") - 540x400 mm (GxD)

DN-49204

EAN 4016032493730



19" 9U duvara monte muhafaza, SOHO PRO 460 x 540 x 400 mm, gri

İster özel alanlarda, ister ofislerde veya dar alana sahip alt dağıtımlar için: SOHO PRO serisine ait kompakt 483 mm (19 inç) çözümlerle ağınızı istediğiniz yere kurabilirsiniz. Dört yükseklik biriminde (4HE, 7HE, 9HE, 12HE) mevcut olan duvar kabinleri, tamamı cam kapı ve çatı ile tabanda bulunan kablo girişi ile donatılmıştır. İç bölüme, okunabilir yükseklik birimleriyle işaretlenmiş bir çift galvanizli 483 mm (19") profil monte edilmiştir. Bunlar derinlik açısından ayarlanabilir. Her bir kabin 1,5 mm kalınlığa kadar çelik sacdan imal edilmiş sağlam bir konstrüksiyondur. Renklendirme, gri (RAL 7035) ve siyah (RAL 9005) olmak üzere standart renklerde elektrostatik toz boyama şeklinde yapılır. Kapı açılma yönü değiştirilebilir. Ağ kabinleri monte edilmemiş şekilde optimize edilmiş Flatpack ile teslim edilir. Montaj birkaç adımda gerçekleştirilir ve adım adım talimatlar içeren ekteki kılavuz sayesinde çocuk oyuncağıdır.

DIGITUS® SOHO PRO duvar kabini serisi, optimize edilmiş Flatpack ile verimli teslimatı ve özellikle kullanıcı dostu kurulumu ile öne çıkmaktadır.

- Koruma sınıfı IP20
- Kapatılabilir güvenli cam kapak
- 200° kapak açılma açısı
- Ön kapıda 1 noktadan kilitleme

- Kabinin içinde ön tarafa monte edilmiş 483 mm (19 inç) profil raylar, galvanizli
- 483 mm (19 inç) profil rayların derinliği ayarlanabilir
- Yüksek yük kapasitesine sahip, toz boya kaplı 1,1 - 1,5 gücünde çelik sac
- Tavanda ve zeminde plastik kapaklı kablo girişi
- Aktif ve pasif havalandırma için havalandırma olukları
- Bileşenler için montaj derinliği maks.: 327 mm
- Ürün boyutları (Y x G x D): 460 x 540 x 400 mm
- Birimler: 9
- Derinlik: 400 mm
- Genişlik: 540 mm
- Kabin tipi: Duvara monte kabin
- Ön kapı: Cam kapı, tek açıklık
- Renk: açık gri, RAL 7035
- Yan paneller: İki taraf
- Yük kapasitesi: 60 kg
- IP koruma sınıfı: IP20
- Monteli: no

Package contents

- Montaj seti (cıvatalar, kafes somunlar, pullar)
- 2x anahtar
- 1x QIG

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	1	11.44	58.00	47.50	17.50	48,212.50
Packaging Unit Inside	1	11.44	58.00	47.50	17.50	48,212.50
Packaging Unit Single	1	11.44	58.00	47.50	17.50	48,212.50
Net single without Packaging	1	10.58	40.00	54.00	46.00	0.00

More images:

DN-42294
Wall Mounting Cabinet SOHO PRO
485mm (19") - 540x400mm (WxD)

Slide the top panel onto the body in the direction of the arrows. The arrows point to the location of the top panel. Push the panel into the panel body of the body. Press the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body.

Insert the bottom panel to the body by 4 screws.

Put the cabinet on the floor. The cabinet must be standing on a flat surface. Insert the screws of the cabinet into the floor. Insert the screws of the cabinet into the floor. Insert the screws of the cabinet into the floor.

Slide the top panel onto the body in the direction of the arrows. The arrows point to the location of the top panel. Push the panel into the panel body of the body. Press the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body.

Slide the top panel onto the body in the direction of the arrows. The arrows point to the location of the top panel. Push the panel into the panel body of the body. Press the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body.

DN-42294
Wall Mounting Cabinet SOHO PRO
485mm (19") - 540x400mm (WxD)

Slide the top panel onto the body in the direction of the arrows. The arrows point to the location of the top panel. Push the panel into the panel body of the body. Press the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body.

Slide the bottom panel to the body by 4 screws. Press the bottom panel into the body. Press the bottom panel into the body. Press the bottom panel into the body. Press the bottom panel into the body.

Put the body on the floor. The body must be standing on a flat surface. Insert the screws of the body into the floor. Insert the screws of the body into the floor. Insert the screws of the body into the floor.

Slide the top panel onto the body in the direction of the arrows. The arrows point to the location of the top panel. Push the panel into the panel body of the body. Press the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body. Insert the top edge of the panel into the groove of the panel body.

