

# DIGITUS Consola modular com TFT de 17" (43,2 cm), KVM de 8 porta & touchpad, teclado britânico

DS-72210-2UK  
EAN 4016032449461



### Modularized 43,2cm (17") TFT console with 8 port KVM, UK keyboard, RAL 9005 black

A consola TFT DIGITUS® 17 "disponibiliza várias opções de configuração individuais graças ao seu design modular, para que possa ser coordenada uma adaptação à área de aplicação da consola. Isto permite economizar custos na consola, podendo ser atualizado ou ajustado a qualquer momento, com módulos adicionais. Graças à configuração flexível, é garantida alta segurança futura da consola. A consola modular consiste num monitor de 17", um computador KVM de 8 portas, um teclado e um touchpad.

### Máxima flexibilidade na administração do farm de servidores

- Monitor TFT 43.2 cm (17"), com revestimento anti-reflexo, vidro de segurança inquebrável
- Resolução: 1280x1024 a 60 Hz
- A consola proporciona mais 85% de espaço
- Proporção de contraste: 1000:1
- Suporta: 16,7 M cores
- Inclui computador KVM de 8 portas
- Inclui teclado britânico
- Rato tátil com duas teclas de função

- A consola pode ser completamente extraída do armário do servidor e o ecrã de TFT pode ser inclinado até 120 graus.
- Peso bruto: 19,15 kg
- Bloqueio de segurança para consolas para evitar ocorrência de danos
- Economia de espaço com caixa (1 unid.), preto (RAL 9005)
- 8 x Cabo de ligação de servidor
- Cascading possible: no
- Interface: VGA
- Keyboard Layout: UK
- Number of ports: 8
- Screen size: 17 inch

### Package contents

- Consola modular 17"
- Computador KVM de 8 portas
- Teclado
- Peso: 20 g
- Fonte de alimentação
- Material de montagem
- 8 x Cabo de ligação de servidor

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm <sup>3</sup>
Packaging Unit Carton	1	23.36	81.00	70.50	19.50	111,355.00
Packaging Unit Inside	1	23.36	81.00	70.50	19.50	111,355.00
Packaging Unit Single	1	23.36	81.00	70.50	19.50	111,355.00
Net single without Packaging	1	12.54	69.50	48.00	4.50	0.00

More images:



Safety notes

- This product is intended for indoor use only.
- Read all instructions.
- Follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- If this appliance falls, it can cause serious damage.
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- This device is designed for the IT distribution system with 100 V - 230 V voltage.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- If an extension cable is used for the appliance, make sure that the total capacity of all products using the cable does not exceed the current load.
- Ensure that the total current of all products connected to the socket does not exceed 15 A.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
- The mains cable or plug is damaged or worn;
- Liquid has penetrated the appliance;
- The device has been exposed to rain or water;
- The device has been dropped or the housing has been damaged;
- The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.

**EU responsible person**

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH  
Auf dem Schüffel 3  
Lüdenscheid, Germany  
<https://www.assmann.com>  
[info@assmann.com](mailto:info@assmann.com)