

DIGITUS Consola modular com TFT de 19" (48,3 cm), KVM de 16 portas Cat.5 & touchpad, teclado americano

DS-72211-5US
EAN 4016032450177



Modularized 48,3cm (19") TFT console with 16 port CAT 5 KVM, US keyboard, RAL 9005 bk

A consola TFT DIGITUS® 19 "disponibiliza várias opções de configuração individuais graças ao seu design modular, para que possa ser coordenada uma adaptação à área de aplicação da consola. Isto permite economizar custos na consola, podendo ser atualizado ou ajustado a qualquer momento, com módulos adicionais. Graças à configuração flexível, é garantida alta segurança futura da consola. A consola modular consiste num monitor de 19", comutador 16 portas Cat.5 KVM, um teclado e um touchpad.

Máxima flexibilidade na administração do farm de servidores

- Monitor TFT 48.3 cm (19"), com revestimento anti-reflexo, vidro de segurança inquebrável
- Resolução: 1366x768 a 60 Hz
- A consola proporciona mais 85% de espaço
- Proporção de contraste: 1000:1
- Suporta: 16,7 M cores
- Inclui comutador KVM de 16 portas Cat. 5
- Inclui teclado americano
- Rato tátil com duas teclas de função

- A consola pode ser completamente extraída do armário do servidor e o ecrã de TFT pode ser inclinado até 120 graus.
- Peso bruto: 19,15 kg
- Bloqueio de segurança para consolas para evitar ocorrência de danos
- Economia de espaço com caixa (1 unid.), preto (RAL 9005)
- 16 x Cat. 5 Chaves
- Cascading possible: no
- Interface: CAT 5
- Keyboard Layout: US
- Number of ports: 16
- Screen size: 19 inch

Package contents

- Consola modular 19"
- Comutador KVM de 16 portas Cat5.
- Teclado
- Peso: 20 g
- Fonte de alimentação
- Material de montagem
- 16 x Cat. 5 Chaves

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	1	23.36	81.00	70.50	19.50	111,355.00
Packaging Unit Inside	1	23.36	81.00	70.50	19.50	111,355.00
Packaging Unit Single	1	23.36	81.00	70.50	19.50	111,355.00
Net single without Packaging	1	12.54	69.50	48.00	4.50	0.00

More images:



Safety notes

- This product is intended for indoor use only.
- Read all instructions.
- Follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- If this appliance falls, it can cause serious damage.
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- This device is designed for the IT distribution system with 100 V - 230 V voltage.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- If an extension cable is used for the appliance, make sure that the total capacity of all products using the cable does not exceed the current load.
- Ensure that the total current of all products connected to the socket does not exceed 15 A.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
- The mains cable or plug is damaged or worn;
- Liquid has penetrated the appliance;
- The device has been exposed to rain or water;
- The device has been dropped or the housing has been damaged;
- The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.

EU responsible person

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH
Auf dem Schüffel 3
Lüdenscheid, Germany
<https://www.assmann.com>
info@assmann.com