

DIGITUS Modular HD LCD KVM console with 19" TFT, 8-port HDMI KVM connection, touchpad, Spanish keyboard layout

DS-72221-6ES EAN 4016032482178





Modulare Konsole with 19 TFT48,3cm 8Port KVM Touch 8 x HDMI, HD Resolution, ES Keyboard

Thanks to its modular design, the DIGITUS® 19" HD TFT console offers a variety of individual configuration options so that it can be adapted to the area of application of the console. This makes the console cost-saving and it can be upgraded or converted with additional modules at any time. The flexible configuration guarantees that the console is highly future-proof. The modular console consists of a 19" monitor, an 8-port HDMI KVM switch and the touchpad.

The console can be completely pulled out of the server cabinet and the TFT screen can be tilted by 120 degrees.

- Resolution: 1920x1080 at 60 Hz
- Console creates up to 85 % more space
- Contrast ratio: 1000:1
- Supports: 16.7 M colors
- 8-port HDMI KVM switch included
- Mouse touch board with two function buttons

- The console can be completely pulled out of the server cabinet and the TFT screen can be tilted by 120 degrees
- Console safety lock to prevent damage
- Interface: HDMI
- Number of ports: 8
- · Screen size: 19 inch
- Broj priključaka: 8
- Cascading possible: Ne
- Raspored tipkovnice: ES
- Sučelje: HDMI
- Veličina ekrana: 19 inča

Package contents

- Modular 19" console
- 8-port HDMI KVM switch
- Keyboard with Spanish keyboard layout
- User manual
- · Power supply unit
- Mounting material
- 8 HDMI + USB connection cable


Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	1	3.20	62.50	75.50	18.60	87,768.80
Packaging Unit Inside	1	3.20	0.00	0.00	0.00	0.00
Packaging Unit Single	1	3.20	62.50	75.50	18.60	87,768.80
Net single without Packaging	0	14.60	44.50	55.55	4.50	11,123.90



More images:















Safety notes

- This product is intended for indoor use only.
- Read all instructions.
- · Follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- If this appliance falls, it can cause serious damage.
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings
 must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- $\bullet\,$ Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- This device is designed for the IT distribution system with 100 V 230 V voltage.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
 Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- If an extension cable is used for the appliance, make sure that the total capacity of all products using the cable does not exceed the current load.
- Ensure that the total current of all products connected to the socket does not exceed 15 A.
- · Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- · Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
- The mains cable or plug is damaged or worn;
- Liquid has penetrated the appliance;
- The device has been exposed to rain or water;
- · The device has been dropped or the housing has been damaged;
- The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.



EU responsible person

 $\label{thm:equired} \mbox{EU based economic operator ensuring the product complies with the required regulations.}$ ASSMANN Electronic GmbH Auf dem Schüffel 3 Lüdenscheid, Germany https://www.assmann.com info@assmann.com