

DIGITUS USB 2.0 sharing switch

DA-70135-3 EAN 4016032480549





USB 2.0 Sharing Switch Button Control, no power adapter

 $\ensuremath{\mathsf{USB}}$ 2.0 Sharing Switch allows maximum two PCs to share one $\ensuremath{\mathsf{USB}}$ device connected. It provides you a great solution to share USB devices between two PCs to save the limited budgets on USB devices and the effort on doing hot-plug process.

No more plugging and unplugging between your computers and USB devices - The USB Sharing Switch allows to share a single USB device (like printers, scanners) between two computers

Compatible to USB 1.1 and USB 2.0 interface

- Selects PCs by using push buttons on top panel
- Compliant with USB 2.0 specifications
- No additional power supply required power supply via USB Supports Windows 10, 8, 7, Vista, XP and Mac OS 10.3 and above

Package contents

- USB 2.0 sharing switch
- 2 x USB 2.0 Connection cables, 1,0m
- QIG (quick installation guide)

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	40	10.30	34.00	43.80	28.00	41,697.60
Packaging Unit Inside	1	0.26	0.00	0.00	0.00	0.00
Packaging Unit Single	1	0.26	9.30	13.50	2.70	338.99
Net single without Packaging	1	0.04	5.90	6.00	2.10	0.00

More images:



















Safety notes

- Overloading can lead to overheating and damage to the appliance or the connected peripherals.
- If necessary, use an external power supply to ensure stable performance.
- If devices such as external hard disks or printers that require a high power consumption are connected, the device should be used with an external power supply. Otherwise, the device could be overloaded or functional problems could occur.
- Do not expose the device to rain, moisture, vapors or liquids.
- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock!
- Ensure adequate ventilation to prevent damage due to overheating.
- Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device.
- Disconnect the appliance from the power supply and the connected devices before cleaning.
- Clean the device with a dust-free cloth.

EU responsible person

 $\hbox{EU based economic operator ensuring the product complies with the required regulations.}\\$

ASSMANN Electronic GmbH Auf dem Schüffel 3 Lüdenscheid, Germany https://www.assmann.com info@assmann.com