Audio Extender over CAT 5, up to 600 m

DS-56100 EAN 4016032366997





DS-56100 audio extender cat.5e 600 met Extension up to 600m, local + remote unit

With the DIGITUS CAT 5 Audio Extender you are able to extend audio stereo and microphone signals up to 600 meter away by using the Audio Extender and one CAT 5 cable. You can connect your audio devices by RCA or 3.5 mm audio cable and the integrated dip-switch enables an easy and fast switching between the connected sources.

Use a simple network cable to extend the audio signal - up to 600 $\mbox{\ensuremath{m}}$

- Place your audio devices wherever you want without audio cable limitations
- Extension of audio signals up to 600m

- Switch between RCA and audio stereo by dip switch
- · Gold-plated RCA contacts
- 1x 3.5mm stereo output
- 1x RCA output
- 1x RJ45
- No power supply needed

Package contents

- 1x Audio Extender Local Unit
- 1x Audio Extender Remote Unit
- QIG (quick installation guide)
- Mounting accessories

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	40	10.50	36.00	23.50	62.00	52.45
Packaging Unit Inside	1	0.26	8.30	11.20	11.50	1,069.04
Packaging Unit Single	1	0.26	8.30	11.20	11.50	1,069.04
Net single without Packaging	0	0.26	7.00	10.80	2.70	204.12

More images:





Safety notes

- If the device is powered by a plug-in power supply, ensure that the power adapter is connected correctly and meets the specified requirements (e.g. voltage and current).
- Only use certified CAT5e or CAT6 cables to ensure stable signal transmission.
- For particularly long cable runs or in environments prone to interference, it is recommended to use shielded network cables.
- Make sure that all connections are tight and secure to avoid loose contacts that could affect the signal quality. Make sure that the HDMI and Ethernet connections are properly connected.
- Make sure that the CAT cable is not laid near high-voltage power lines or other strong sources of electromagnetic interference to avoid signal interference.
- Only operate the device within the specified temperature range.
- Do not use the device outdoors or in damp or wet environments
- Check all connections and cables regularly for wear or damage. Cables and connections can wear out, especially with frequent use or long installations, which can lead to poor signal quality or system failure.